

Miniwrap 100

2015

User's Guide



POMI Industri ApS

Abildvadvej 5, Thorup, DK-9610 Nørager

Tel. +45 98 55 20 00, Fax +45 98 55 22 00, Mobile +45 40 34 20 10

E-mail: pomi@pomi.dk - Hjemmeside: www.pomi.dk

Contents

1.	POMI MINIWRAP 100	3
2.	SAFETY DETAILS.....	3
3.	EU DECLARATION OF CONFORMITY.....	4
4.	IDENTIFICATION OF THE MACHINE.....	5
5.	LIFTING THE WRAPPER	6
6.	SETTING/ADJUSTING THE WRAPPER.....	7
6.1.	ADJUSTING THE FRONT BED	7
6.2.	SHIFTING THE DRAWBAR.....	8
6.3.	ADJUSTING THE BELT	9
6.4.	BALE STOP ON BELT	9
6.5.	WRAPPER BALE STOP SENSOR	10
6.6.	BELT TENSIONER.....	10
6.7.	ADJUSTING THE BALER TABLE CHAINS.....	11
6.8.	ADJUSTING THE PRESSURE ON THE UPPER PART	11
6.9.	GRIPPER ADJUSTMENT	12
6.10.	KNIFE ADJUSTMENT	12
6.11.	ADJUSTING THE COLLECTOR TABLE BALE SENSOR	13
6.12.	REAR DOOR ADJUSTMENT	13
6.13.	SENSOR OVERVIEW	14
7.	OPERATING THE WRAPPER	16
7.1.	CONNECTION OF OIL	16
7.2.	CONNECTION OF ELECTRICITY	16
7.3.	COMPUTER.....	17
7.4.	INSTALLATION OF FILM ROLLS	18
8.	HYDRAULIC DRIVE	20
8.1.	HYDRAULIC DIAGRAMS.....	21
9.	COMMON FAULTS.....	26
10.	TECHNICAL DATA	27

Updated 28.02.18

1. Pomi Miniwrap 100

Before using the Miniwrap 100, please take care to carefully read these instructions. The operator should have sufficient knowledge of the design and operation of the wrapper and know how to maintain it properly as this is essential to safe operation of the wrapper.

Thank you for choosing a POMI Miniwrap 100, you may use it for straw and silage.

If you want to use it for other crops, please contact the manufacturer to have his written approval.

2. Safety details

FOR YOUR OWN SAFETY

- **Never move about on or work on the machine unless the tractor engine has been stopped and the control box emergency stop button has been activated.**
- **Do not allow unauthorised persons within a distance of 10 metres from the machine when it is in operation. There are two reasons for this: partly the machine may suddenly move and partly oil may squirt from a damaged tube.**
- **All lamps must function as provided in your national road code.**
- **Drive sensibly when moving the machine as fierce driving strains both the wrapper and the baler. POMI disclaims any liability for damage to the baler.**
- **Remember to re-torque the wheels and wheel axle.**
- **Avoid hitting kerbstones and bumps at high speeds.**

3. EU Declaration of Conformity

Manufacturer: POMI Industri ApS
Abildvadvej 5, Thorup
DK-9610 Nørager
Tel. +45 98 55 20 00

Company

Declares THAT

Machine: Miniwrap 100 _____
Brand serial no., year

has been produced in conformity with the provisions of Council Directive 89/392/EEC of 14 June 1989 on the mutual approximation of the laws of the Member States relating to machinery as amended on 20 June 1991 (91/368/EEC) (93/44/EEC) and (93/68/EEC) with special reference to Annex I of the Directive relating to material safety and health requirements in connection with the design and manufacture of machinery.

Especially:

has/have been manufactured in conformity with the following harmonised standards (subart. 2 of Article 5 of the Directive)

has/have been manufactured in conformity with other standards and/technical provisions.

Signature

Date:

Poul Mikkelsen
Managing Director
POMI Industri ApS

4. Identification of the machine

Please state the serial number of the machine when ordering spare parts. You will find the serial number on the type plate on the left side of the machine (see ill.).



Serial no. _____


5. Lifting the wrapper



If you need to lift the wrapper using a crane, mount the straps as shown in the illustrations. In this position the machine is in a reasonable state of equilibrium.


6. Setting/adjusting the wrapper

6.1. Adjusting the front bed




When installing the wrapper on the baler, it is important to ensure as high a pressure on the baler as possible, preferably so the bales start to glide up as soon as they run off the baler. This ensures the smallest possible pitch on the belt and prevents the bales from stacking up. Adjust the height of the front wrapper table at the two connecting rods (1) to bring the wrapper table to a horizontal position or to a slight forward tilt.

6.2. Shifting the drawbar




The drawbar can be set in 2 positions: Pos. 1 is working position. Pos. 2 is road haulage for centre mounted balers.

6.3. Adjusting the belt




Adjust the belt sideways by slackening the bearings; next adjust the two screws so the belt runs across the middle of the rollers.

6.4. Bale stop on belt



The arm of the bale stop can be adjusted by the forward length: move the bolt (1). The sensor (2) can be moved forwards and backwards in the oblong hole to shift the location where the bale stops relative to the wrapper section.

6.5. Wrapper bale stop sensor



1

The sensor arm (1) can be moved stepwise by loosening the screw holding the white rod. Adjust and retighten.


6.6. Belt tensioner



1

Tension the belt by shifting the tensioning wheel (1)

6.7. Adjusting the baler table chains




Adjust the chains by slackening the bearings at the tensioning end of the chains. Tension the chains using the screw (1). It is recommended to ensure as slack a tensioning as possible; however, the pushers must not touch the yellow plate (2).

6.8. Adjusting the pressure on the upper part




Tension the springs if the baler table cannot retain the bales.

6.9. Gripper adjustment



The gripper can be moved in the oblong holes (1). The travel of the gripper can be adjusted on the cylinder fork (2).

6.10. Knife adjustment



The knife can be adjusted in the oblong holes (1)

6.11. Adjusting the collector table bale sensor



1

Adjust the sensitivity of the bale sensor by shifting the plate (1).

6.12. Rear door adjustment



1




2

It is recommended to adjust the position of the rear door (see ill.). Adjust the position on the cylinder fork (2).

6.13. Sensor overview


Sensor 1 Ballstop on belt.

Stops belt when activated.




Sensor 2 Load arm out.

Turns off when the load arm is out, turns on and keeps light when the arm moves.



Sensor 3 Load arm in.

Turns on when load arm is in. Turns off when arm is on its way out.



Sensor 4 Balestop in wrapper.

Activates when a bale comes in.

Stops loading so the bale is right located.




Sensor 5 Rotor switch.

Lights each time a foil arm passes.

Sensor 6 Bale pos. max. error switch.

You can adjust the bale pos. max. error in the menu so the bale stops on the surface. If the value is too high the bale stands skewed. If it is too low, the bale continues to rotate.



Sensor 7 Switch roller path.


Turns off when a bale activates the arm.

Sensor 8 Collecting table in.

Turns off when the push arm is in and keeps light for the rest of the time.


Sensor 9 Collecting table out.

Turns off when the arm is out and keeps light for the rest of the time.



7. Operating the wrapper

7.1. Connection of oil



Connect the oil so the flow is through the filter.

If LS is to be connected, connect the LS hose from the valve block at the LS (1) imprint over to the LS of the tractor, and turn the switch on the back of the block to LS. Make sure the switch (2) is on F when using a closed circuit and permanent pump. The hydraulics block is marked with F and LS.

7.2. Connection of electricity

There are numbers on wires.

Wire 1 is -

Wire 2 is +

7.3. Computer


Take care when setting the number of plastic layers to be wrapped around the bales. Check regularly. Check by counting the number of machine revolutions. If you know how many bales can be wrapped using one roll, you can also use this value to check.

We disclaim liability for faulty wrapping.




User guide for computer

See Technical Documentation - POMI WRAP 100.




7.4. Installation of film rolls

Set the computer to service function.



Feed the film through the pre-stretchers as shown above.



1

Attach the end of the film to retainer (1).



Turn the rotor using button (1).

Install the second film roll and attach the end of the film to the same retainer.

8. Hydraulic drive

The hydraulic block features a number of flow control valves and pressure-relief valves.

There are flow control valves for the following functions:

See also the hydraulic chart A51358-51217.

Belt

Load arm

Gripper arm


Door

Pusher

Adjust the above flow control valves on the hydraulic block: Loosen a counter nut, next turn a socket screw in or out. If it is turned out, the speed is increased. Locate the specific flow control valve on the block by studying the diagram. Let us say you want to increase the speed of the gripper arm: See diagram A51358-51217. Locate the gripper arm by working your way through the diagram. Here you will find a valve termed FDBA-D. Locate the corresponding ID on the hydraulic block. Adjust this valve by screwing it half a turn – check whether this is sufficient.


There is also a pressure-relief valve for the pusher arm and the load arm. The pressure can be increased or reduced, as required. If the pressure is increased excessively, this may damage the machine.

8.1. Hydraulic diagrams



NOTES

REFER TO SUN HYDRAULICS TECHNICAL LITERATURE AND CATALOGUE FOR DETAILS OF CARTRIDGE STANDARD SETTINGS, ADJUSTMENT RANGES, MAXIMUM PRESSURE RATINGS, SEAL MATERIAL, TORQUE VALUES, ETC.



UNRECORDED DRAWING FOR CUSTOMER APPROVAL

UNLESS OTHERWISE SPECIFIED	TITLE	CUSTOM	SHUTTLE	REVISION PART NO. SHEET 1 OF 2
DIMENSION TOL	VALVEPAC	MANIFOLD	A902-10V-J06	
1" = .030	REF. EQ203176	MATERIAL	ALUMINIUM	
.XX = .015	HYDROPOWER	HEAT TREAT & FINISH		
.XXX = .005	DRAWN M.SAGE	RELEASE	LK02398	
ANGLE TOL 2/3	DATE	DATE	DATE	
FORMS ALL	18 FEB 88	28 FEB 88	24 FEB 88	
REWORKS				
LET	REVISION	DATE	DRN	CHK

SEE SHEET 2 FOR REVISION FOR DETAILS




WELER ROAD, WHITELY MITTED
 COVENTRY, CV3 4LA ENGLAND
 TELEPHONE (0247 7621 7400)



NOTES

REFER TO SUN HYDRAULICS TECHNICAL LITERATURE AND CATALOGUE FOR DETAILS OF CARTRIDGE STANDARD SETTINGS, ADJUSTMENT RANGES, MAXIMUM PRESSURE RATINGS, SEAL MATERIAL, TORQUE VALUES, ETC.

UNCHECKED DRAWING
FOR CUSTOMER APPROVAL



SYMBOL

6	500-001-012	O-RING SEAL	13
5	330-018-001	HEX.SKT.PLUG	6
4	XZOD-XXN	CAVITY PLUG	1
3	CSAZ-XXN	SHUTTLE VALVE	5
2	CSAX-XXN	SHUTTLE VALVE	5
1	173-111	ALUMINIUM BODY	1
I		PART NO.	
T		SETTING/MATERIAL	
E			
M		PART NAME	

TITLE	CUSTOM VALVEPAC	SUN HYDRAULICS®
CARD REF.	EQ203176	MANIFOLD
SCALE	1:*	ALUMINIUM
DRAWN	HYDROPOWER	HEAT TREAT & FINISH
CHECK	M.SAGE AP	
RELEASE	UK62388	
DATE	10 FEB 89	
DATE	20 FEB 89	
DATE	24 FEB 89	



UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES			
X	± 0.30		
.XX	± 0.15		
.XXX	± 0.05		
ANGLE TOL	± 1/2		
FINISH	80 ✓		
REVISION		DATE	DRN CHK REL
A	FIRST RELEASE		MS DRC
B	RE-DESIGN IN LINE WITH A982-05V-J06 - UK62476		
C			
D			
E			

9. Common faults

Fault	Remedy
Film ruptures when started	<p>There may be plastic residue in the gripper. Clean out.</p> <p>The rotor overruns and makes the plastic stick to the gripper when it is drawn downwards. Adjust in the computer: either reduce the time function of the rotor or reduce the end speed of the rotor.</p> <p>Adjust the knife if the plastic is cut too early, meaning that the gripper does not catch it.</p>
Film ruptures during wrapping	<p>Check that the pre-stretchers run lightly. If they are worn or damaged: replace.</p> <p>The film roll runs up leaving the plastic slack. When the machine is started again, the film bursts. Reduce the speed of the rotor. The spring that keeps the rollers against the film should be tighter.</p>
Bale gets stuck in the plastic when it is pushed out of the wrapper table.	<p>Check the knife, replace or adjust, as required.</p>
Bale is on its side when it reaches the collector table.	<p>Increase the speed of the wrapper table. Check whether the bale sticks to the plastic ends; adjust knives, if necessary.</p>
Bale is not positioned on the flat surface when finally wrapped.	<p>Adjust Bale pos. max. error. If the value is too high the bale stands skewed. If it is too low, the bale continues to rotate.</p>
Machine has stopped and will not restart.	<p>Check that the load arm is in the correct position.</p> <p>Check that the rotor is in the correct position.</p> <p>Check that the collector table pusher is in the correct position.</p> <p>Check that the last bale has left the machine and has activated the collector table sensor.</p> <p>Stop the machine, press reset and restart.</p>

10. Technical Data

Oil consumption	60 litres
Hydraulic oil connection	1 double-acting/Min. 150 Bar
Current	12 V
Width during transportation	2.65 metres
Length	3.80 metres
Height	2.20 metres
Weight	850 kg
Wheels	2 x 26-12 D = 640 mm
Max. bale compression	10 cm